

Item No. 20004941 **\$160.41**

Conveyor Leveling Jig

Feature: Conveyor Leveling Jig assists in the alignment and leveling of conveyor sections

Leveling Instructions:


- STEP 1:** Using the Leveling Jig and starting at the take-up section place the short side (7in) of the jig on the conveyor and the other side (8.5in) on the floor.
- STEP 2:** Place the level on top of the Jig and add the 1/4in shim plates under the jig on the conveyor side until conveyor is level.




STEP 1




STEP 2



Conveyor Leveling for Front Wheel Pull



Conveyor Leveling for Rear Wheel Push



Product Specifications

Type	Conveyor Leveling Jig
Material	Aluminum
Length	64in
Width	12in
Height	8.5in and 7in

